



matting / athletics / flooring

TEEBAUD INSTALLATION

INSTRUCTIONS OVERVIEW

This installation guide is intended to provide the necessary information for the proper installation of the rolled goods products listed below. These instructions are believed to be based upon accepted industry standards and are provided for informational use only. Edgewood Matting Ltd. does not warranty any installation performed pursuant to these instructions or otherwise and specifically disclaims liability for any direct or indirect personal injury, property damage or other costs or losses resulting from installation. The products listed below should be installed by qualified and experienced personnel. These instructions are intended for: Teebaud

UPON RECEIVING PRODUCT

1. Verify packing slip matches for product, color, size and quantity
2. Inspect delivered product thoroughly. Report any discrepancies of original order, produce defects, etc. NO reimbursements/warranty claims will be given for labor on material installed with visual defects. Any defects, size, color, or otherwise, must be reported to the place of purchase prior to installation.
3. Store product in clean, dry environment with temperatures between 21° – 35°C (70° - 95°F)
4. Read product and floor preparation, instructions, warranty and other disclaimers carefully and completely before beginning any installations.

PREPARATION

Tools needed:

- Measuring Tape or Ruler
- Metal Straight Edge
- Non-Retractable Utility Knife with extra blade or Scissors

PRE-INSTALLATION CLEANING

1. In any type of matting installation the floors are to be cleaned of debris by sweeping up the larger debris followed up by vacuuming the area for fine grains of smaller debris.
2. Do not install Teebaud on a wet floor.

WARNING: Failing to clean properly will cause the adhesive to be less effective or not effective at all. Failing to clean properly under a loose lay mat can cause potential mat movement and unnecessary wear.

INSTALLATION INSTRUCTIONS

Interior Use Only

Note: In order to obtain a long lasting non skid performance avoid frequent removal and re-installation of Teebaud from its designated installation area

Installing Teebaud Over Carpeting

1. Cut Teebaud 1” to 3” smaller than the areas of the mat to be installed.
2. Remove the plastic release liner.
3. Place Teebaud white side down, facing the wall to wall carpeting.
4. Then place mat on top of Teebaud’s gray side.

Installing Teebaud Over Smooth Flooring

1. Cut Teebaud 1” to 3” smaller than the areas of the mat to be installed.
2. Remove the plastic release liner.
3. Place Teebaud grey side down, facing the smooth floor.
4. Then place mat on top of Teebaud’s white side.

Oversized Mats

If several pieces of Teebaud are necessary for one mat, simply apply as many pieces as needed, side by side. Taping or splicing is NOT necessary.

CLEANING

Teebaud can be hand rinsed and air dried. Teebaud when installed on a smooth surface may leave an inoffensive light residue which is water soluble. The residue can be cleaned with water or common household cleaners, such as Orange Glo Everyday Floor Cleaner for Hardwood Floors or Bonakemy, subject to specific floor finish/surface manufacturers guidelines.