



matting / athletics / flooring

3M™ NOMAD™ SCRAPER MATTING 9100 INSTALLATION

IMPORTANT

1. 3M™ Nomad™ Scraper Matting 9100 removes and hides large amounts of dirt. This dirt should be removed from beneath the mat on a regular basis.
2. Do not use 3M™ Nomad™ Scraper Matting 9100 around chlorinated or hydrocarbon solvents, for example methylene chloride or mineral spirits. Additionally, these solvents should not be used to clean 3M™ Nomad™ Scraper Matting 9100.
3. Install the mat with the flat side down. The Z-web extends above the straight rib on the top side. The top side is rougher in order to remove dirt and debris.

3M™ Nomad™ Scraper Matting 9100 can be used as an entry mat outdoors, indoors or in recessed mat wells. When used indoors, the mat is not recommended for use over carpet because of the mat's open construction. From all entryway applications, place the matting so that all persons entering the building take several steps on it before proceeding into the building. 3M™ Nomad™ Scraper Matting 9100 is an excellent work area mat for industrial applications.

INSTALLATION

For best results follow these guidelines:

1. Unroll all the matting at or near the actual area in which it is to be used. Allow the mat to relax and come to room temperature (70°F, 21°C) for at least 2 hours. Unrolling the matting the night before an installation is preferred.
2. When moving the mat, do not stretch it. When possible, the product should be installed with the length of the material perpendicular to the direction of traffic.
3. Use a utility knife and a straight edge for cutting. Do not use scissors.

4. Install the mat with the flat side down. The Z-web extends above the straight rib on the top side. The top side is rougher in order to remove dirt and debris.

PREPARATION FOR RECESSED WELL INSTALLATION

1. The material well must be clean with no build-up of dirt or other material on the edges, bottom or the corners. A scraper may be necessary to clean the well. The mat well should have an even depth and a flat surface with no bumps or large ridges. Measure each side of the well to ensure the sides are straight and square.
2. A maximum well depth of 1/2 inch (13 mm) is recommended. Various materials, such as rubber and plywood, can be used to adjust the well depth.
3. Carefully measure the recessed well to determine which direction to place the matting for minimum cutting and the least amount of waste. If possible avoid very small pieces.
4. Determine which side of the matting is the top side. The roughest edge should be exposed to remove dirt.

CUSTOM CUTTING FOR RECESSED WELL INSTALLATION

1. Place the relaxed mat flat side down against one edge of the well without stretching it. Force as much matting as possible into the well. Use of a foot to force the mat into the well is recommended.
2. Place sections into the well until the well is filled.
3. Allow 1/8 inch (3.5 mm) of extra material per 6 feet (2.0 m). Cut the last edge using a utility knife and a straight edge. Cut the mat while it is in the well to minimize movement. Force the extra material into the well. If it buckles you may need to cut off a small portion on the edge.

4. It may be necessary to cut the last section of matting to the exact width required. To do this, measure and mark the matting. Add an additional “row” of matting elements to the measurement and cut at that point. Force the last piece of matting into the well.
5. Place a weight, such as a board along the full length of the edging to assure a maximum strength bond. Allow to dry at least 8 hours before placing matting into service.

CUSTOM CUTTING FOR INSTALLATION OVER FLAT SURFACE

1. If the mat is to be placed on a flat surface, prepare the matting and measure it after it is allowed to relax and come to room temperature. Cut it using a utility knife and a straight edge.
2. If several pieces are to be placed side by side, prepare all the matting in the same manner. Measure and cut the matting after it is allowed to relax and has come to room temperature. Be careful not to stretch the matting while cutting.

ALTERNATIVE MAT EDGING

Matting edging can be easily applied to 3M™ Nomad™ Scraper Matting 9100.

Tools and Materials needed:

- Utility knife
- Straight edge
- 3M™ Matting Edging (kit or roll)
- 3M™ Matting Adhesive (a 3-ounce tube will apply about 15 feet or 4.5 m)

For the best results follow these guidelines:

1. Before applying edging, be certain that the matting and edging are relaxed and not stretched. Unroll the matting and edging and allow them to relax and come to room temperature. Do not stretch matting when applying edging (see Installation guidelines).
2. Be certain side to be edged are straight. Trim edges with a utility knife (not scissors) and a straight edge if necessary. (see Custom Cutting instructions)

Edging Instructions:

1. Cut length of edging to same length as edge of matting.
2. Place edging flat on the floor, grooved side up.
3. Apply 2 beads of adhesive, one in a straight pattern following the inside edge and the other in a “zig-zag” pattern staying ¼ inch (6 mm) from edge.
4. Place bottom side of the matting edge on top of the edging flap containing adhesive and apply moderate pressure.